

Release: July 2024

Recommendations for usage of liquid soaps in Wagner - EWAR soap dispensers

Warranty:

For the intended use and the usage of following recommended soaps we grant for our soap pumps 1 year warranty after putting in operation.

Recommended liquid soaps:

We are recommending Wagner Ewaderm Soft or Wagner Ewaderm Sept liquid soaps (always available in disposable bottles and in 10l canisters) or always synthetic soaps with following specifications:

Anionic tensides:	≤ 30%
Non - anionic tensides:	≤ 9%
Perfume/oil/alcohol or similar:	≤ 1%
Ph - value	6,5 ± 0,5
Animal or vegetable fat/oil:	≤ 1%
Viscosity:	ca. 1600 - 2000 mPa s (at 20°C)

Liquid soaps that do not satisfy the specification mentioned above, are not suitable for usage in Wagner EWAR soap dispensers.

Attention:

Never use disinfectants or soaps with alcoholic or other solvents in our soap dispensers! These substances are destroying the gaskets of the soap pump already after a short term use. We cannot allow any warranty claims caused by usage of these substances. For replacing of destroyed gaskets upgrade sets are available from Wagner - EWAR.

Only our disinfectant dispensers are suitable for usage of disinfectants or soaps with disinfectant ingredients!